

## LIGHTED WALL- MOUNTED MIRROR INSTRUCTION SHEET

92505HW 92515HW 92525HW 92535HW 92545HW 92555HW  
92565HW 92575HW 92585HW 92595HW 925135HW

### OPERATING INSTRUCTIONS

1. Turn switch to the "OFF" position. Plug cord into any standard 120 volt wall outlet. Turn switch to the "ON" position.
2. Lighted mirror will rotate so that you can use either the normal, flat mirror or 5X magnifying mirror located on the opposite side.
3. After use, always turn switch to the "OFF" position.
4. Unplug it from outlet when not in use.

## IMPORTANT SAFETY INSTRUCTIONS

**THIS APPLIANCE IS INTENDED FOR HOUSEHOLD USE. WHEN USING ELECTRICAL APPLIANCES, BASIC SAFETY PRECAUTIONS SHOULD ALWAYS BE FOLLOWED, INCLUDING THE FOLLOWING:**

- WARNING-** To reduce the risk of burns, electrocution, fire, or injury to persons:
1. Read all instructions before using the appliance and keep them for later reference.
  2. To protect against electrical hazards, do not use while bathing or in the shower and do not touch plug or switch with wet hands.
  3. To reduce the risk of burns.
    - 3.1. Avoid swivel the makeup mirror into horizontal position when turn switch to "ON".
    - 3.2. Do not touch the housing especially the top half and mirrors when turn on the switch or off within 10 minutes.
  4. Repairs and service should always be carried out by an authorized service center. Do not use the appliance if it is damaged or if the cable is damaged. Instead, send it to a service department.
  5. Be sure mirror is not in a position where it can reflect sunlight; reflected sunlight can cause fire.
  6. After use, always pull the plug from the socket.
  7. Handle cord carefully for longer life; do not jerk or strain at plug connections, or wrap cord around mirror for storage. This could cause damage to the cord and short circuit. To store mirror, coil cord loosely.
  8. Use only the original accessories supplied.
  9. Allow the light bulb in the mirror time to cool down before storing it away.
  10. Do not lay a switched appliance on soft furnishings, such as a bed, cushion, etc. This will prevent over-heating.
  11. Instruct young children about the dangers and safety rules concerning electrical equipment.
  12. Never let young children use electrical equipment without supervision.
  13. Turn switch to "OFF" position and unplug cord before replacing light bulbs.
  14. Do not place, hang or store appliance where it can fall or be pulled into a tub or sink.
  15. If an appliance falls into water, unplug it immediately. Do not reach into the water.
  16. Never use while sleeping.
  17. Do not place in or drop into water or other liquid.

## TROUBLE SHOOTING

If there is still no light, unplug the lighted mirror and call the manufacturer.

## CLEANING AND MAINTENANCE

Always unplug lighted mirror first. Clean the outside of appliance with a damp cloth. Never immerse it in water or any other liquid. Clean mirror surfaces with a glass cleaner. Do not light until you are certain mirror is completely dry to protect against electrical hazards.


This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:  
(1) This device may not cause harmful interference, and  
(2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
-Reorient or relocate the receiving antenna.  
-Increase the separation between the equipment and receiver.  
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
-Consult the dealer or an experienced radio/TV technician for help.


The users manual or instruction manual for an intentional or unintentional radiator shall caution the user that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

## INSTALLATION INSTRUCTIONS


1. Aptations, Inc recommends using a qualified electrician for all electrical wiring procedures and installations.
2. A standard 120 Volts AC electrical box must be installed at the desired location of the wall before continuing.
3. Remove the mounting screws on both sides of the mirrors base.



4. Remove the mounting plate from the base.




5. Secure the mounting plate to the electrical box on the wall with four(4) wall anchors and mounting screws.



6. Connect the electrical wires coming from the electrical box to the terminal connections. Tighten the set screws.


Wire references are:

- L** — Live wire/Line/Phase (Black wire)
- N** — Neutral (White wire)
- ⊖** — Ground (Green/Yellow wire)



7. Finish installing mirror by mounting base of mirror over the base plate that is attached to the electrical box.

8. Fasten the mounting screws on both sides of the base.



9. Put mirror at desired position and turn black rocker switch on for use.

Please turn over

Front

925X5HW (Eng.)  
User Manual

Back

Dim: 227mm (W) x 300mm (H)  
Letter height at less 1.6mm